

LĀKLAND®

LAKLAND PRODUCTION BY SERIAL NUMBER

4-94, 4-63, 4-76, 4-07

1-104 1995
105-142 1996
143-246 1997
247-312 1998
313-418, 99-01-99-20 1999
419-479 2000
480-580 2001
581-627 2002
628-663 2003
664-683 2004
684-766 2005
767-795 2006
796-816 2007
817-892 2008
893- 2009

55-94, 55-63, 55-76, 55-07

5001-5068 1996
5069-5232 1997
5233-5559 1998
5560-5905, 99-01-99-20 1999
5906-6089 2000
6090-6381 2001
6382-6553 2002
6554-6683 2003
6684-6802 2004
6803-6915 2005
6916-6996 2006
6997-7080 2007
7081-7160 2008
7160- 2009

DARRYL JONES

DJ01-DJ09 2006
DJ10-DJ19 2007
DJ20-DJ29 2008
DJ30- 2009

JOE OSBORN 4 STRING

JO 1-JO52 1998
JO53-JO115 1999
JO116-JO164 2000
JO165-JO212 2001
JO213-JO263 2002
JO264-JO313 2003
JO314-JO335 2004
JO336-JO384 2005
JO385-JO439 2006
JO440-JO505 2007
JO506-JO560 2008
JO561- 2009

JOE OSBORN 5 STRING

5JO01-5JO07 2001
5JO08-5JO30 2002
5JO31-5JO53 2003
5JO54-5JO76 2004
5JO77-5JO93 2005
5JO94-5JO115 2006
5JO116-5JO128 2007
5JO129-5JO140 2008
5JO141- 2009

DECade

D01-D06 2004
D07-D09 2005
D10-D25 2006
D26-D44 2007
D45-D68 2008
D69- 2009

DECade 5 STRING

5D01-5D02 2008
5D03- 2009

BOB GLAUB 4 STRING

BG01-BG94 2001
BG95-BG115 2002
BG116-BG139 2003
BG140-BG165 2004
BG166-BG240 2005
BG241-BG288 2006
BG289-BG332 2007
BG333-BG410 2008
BG411- 2009

BOB GLAUB 5 STRING

5BG01- 2009

HOLLOWBODY

HB01-HB11 2000
HB12-HB43 2001
HB44-HB67 2002
HB68 2003
HB69-HB72 2004
HB73-HB84 2005
HB85-HB89 2006
HB90-HB91 2007
HB92-HB95 2008
HB96- 2009

JERRY SCHEFF 4 & 5 STRING

JS01-JS13 2001
JS14-JS15 2002
JS16 2005
JS17-JS18 2008
JS19- 2009

SKYLINE SERIES

The first two digits of the serial number indicate the year in which the bass was made .